

12Ft. Deluxe Raised Bed Instructions

N.B: The illustrations show a Deluxe 14 inch high bed being assembled. The 9 and 21 inch high beds use the same procedure with the appropriate single or triple tier construction.

9 INCH HIGH FLAT PACK CONTAINS:

2no. 23cm high treated timber side planks. 2no. 23cm high treated timber end planks,
6no. 11 x 11 x 23cm treated timber fixing posts with 14 galvanized brackets . 56 screws.

14 INCH HIGH FLAT PACK CONTAINS:

4no. 23cm high treated timber side planks. 4no. 23cm high treated timber end planks,
6no. 11 x11 x 36cm treated timber fixing posts with 14 galvanized brackets . 112 screws.

21 INCH HIGH FLAT PACK CONTAINS:

6no. 23cm high treated timber side planks. 6no. 23cm high treated timber end planks,
6no. 11 x 11 x 54cm treated timber fixing posts with 14 galvanized brackets . 168 screws.

All configurations are supplied with mounting brackets and a right angled fixing guide.
The fixing guide is used to position the mounting brackets accurately on the corner posts.

